

# Z-1070 Series

# **Pocket-Size Personal Data Collector**

**Buyer's Guide** 



**July 2007** 

# 1. Z-1070/1071 CCD & Laser Pocket-Size Personal Data Collector



MODEL NO	FEATURE	ZEBEX STD P/N	REMARK
Z-1070	CCD 32KB Personal Data Collector with Display w/Zebex Hardware Library & RS-232 Cable	881-7000R9-001	Main Unit
Z-1070BT	CCD 64KB Personal Data Collector with Display w/Zebex Hardware Library, RS-232 Cable & Charger	881-70BTR9-101	Main Unit
Z-1071	Laser 32KB Personal Data Collector with Display w/Zebex Hardware Library & RS-232 Cable	881-7100R9-001	Main Unit
Z-1071BT	Laser 64KB Personal Data Collector with Display w/Zebex Hardware Library, RS-232 Cable & Charger	881-71BTR9-101	Main Unit

# 2. ACCESSORIES

### 2.1 Serial Communication Cable



MODEL NO	FEATURE	ZEBEX STD P/N	REMARK
Serial Communication Cable	Serial Communication Cable for Personal Data Collector	170-00R049-180	Main unit

PIN-OU	T CONFIGURATION
DB-9 (F	emale)
2	TxD(Transmit data)
3	RxD(Receive data)
5	GND(Signal Ground)
DC-IN	9V(charge Voltage)
MINI U	SB port
1	Vpp (DC 9V In)
2	RxD (Receive data)
3	TxD (Transmit data)
4	~Online
5	GND

### 2.2 USB-232 Bootload Cable



MODEL NO	FEATURE	ZEBEX STD P/N	REMARK
JSB Bootload Cable	USB-232 Bootload Cable with Switch for Z-1060/1070/1071	170-00U309-150	Main Unit

PIN-OU	T CONFIGURATION
STAND	ER USB A TYPE
1.	Vcc+
2.	D-
3	D+
4	GND
MINI U	SB Port
1	Vpp (DC 9V In)
2	RxD (Receive data)
3	TxD (Transmit data)
4	~Online
5	GND

# 2.3 USB-HID Cable



MODEL NO	FEATURE	ZEBEX STD P/N	REMARK
USB-HID Cable	USB-HID Cable for Z-1070/1071	170-00R039-200	Main Unit

PIN-OU	T CONFIGURATION
STAND	ER USB A TYPE
1.	Vcc+
2.	D-
3	D+
4	GND
MINI U	SB Port
1	Vpp (DC 9V In)
2	RxD (Receive data)
3	TxD (Transmit data)
4	~Online
5	GND

# 2.4 USB-232 Charging to PC Cable





PIN-OU	PIN-OUT CONFIGURATION		
STANDE	ER USB A TYPE		
1.	Vcc+		
2.	D-		
3	D+		
4	GND		
MINI U	SB Port		
1	Vpp (DC 9V In)		
2	RxD (Receive data)		
3	TxD (Transmit data)		
4	~Online		
5	GND		

# 3. BATTERY PACK BATTERY PACK



MODEL NO	FEATURE	ZEBEX STD P/N	REMARK
AAA.Ni-NH Battery	AAA, Ni-MH, 900mAH Rechargeable battery, with a detect shield on shell x3	862-203000-K01	Main Unit

### **4.POWER SUPPLY**

### PSU-20-UR




MODEL NO	FEATURE	ZEBEX STD P/N	REMARK
UR ADAPTER	AC Adaptor, 100-240 VAC / 9VDC 1A, flat pins, for North America, Japan, Taiwan	11S-90009D-906	Main Unit

# PSU-20- UE



MODEL NO	FEATURE	ZEBEX STD P/N	REMARK
UE ADAPTER	AC Adaptor, 100-240 VAC / 9VDC 1A, round pins, for Europe, Middle East, South East Asia, South America	11S-900R53-006	Main Unit

# 5. HAND STRIP



MODEL NO	FEATURE	ZEBEX STD P/N	REMARK
Hand Strip	Hand Strip	623-210700-041	Main Unit

### 6. BT CHARGER



MODEL NOFEATUREZEBEX STD P/NREMARKBT ChargerZ-1070BT Charger (for Z-107XBT series)881-70CR00-001Accessory

### 7.DONGLE



MODEL NO FEATURE ZEBEX STD P/N REMARK
Dongle Blue tooth dongle (for Z-107XBT series) 836-1070BT-00U Accessory

#### **8.HOW TO PLACE ORDER**

- 1. Make sure the mode and specification of Z-1070 series.
- 2. And also whether you need communication cradle and cable.
- 3. Choose the appropriate power adapter.
- 4. If the required cable or adaptor cannot be found in this selection guide, please contact ZEBEX or local ZEBEX' dealer.

ITEMS	P/N	Z-1070	Z-1070BT	Z-1071	Z-1071BT
RS-232 Cable, USB-232 Cable, USB-HID Cable,	170-00R049-180 170-00U309-150 170-00R039-200	Main Unit	Main Unit	Main Unit	Main Unit
USB-232 Charging Cable	170-00U0X0-150				
(Select 1)					
Adaptor(Select 1)	11S-90009D-906 11S-900R53-006	Main Unit	Main Unit	Main Unit	Main Unit
Battery Pack	8862-203000-k02	Main Unit	Main Unit	Main Unit	Main Unit
Hand Strip	623-210700-041	Main Unit	Main Unit	Main Unit	Main Unit
WinTaskGen & User's Manual	594-000000-800	Main Unit	Main Unit	Main Unit	Main Unit
BT Charger	881-70CR00-001	Accessory	Accessory	Accessory	Accessory
Dongle	836-1070BT-00U	Accessory	Accessory	Accessory	Accessory